INSTALLATION INSTRUCTIONS FOR FIXTURE
#3000F2-SG. #3000F2-OS.

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER.
AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

ASSEMBLING THE FIXTURE (FIG. 1)

1. Disconnect power at main electrical panel before installation.
2. Thread the mounting screws into the same side of the mounting strap as the GREEN ground screw.
3. Guide fixture wires through hole in center of mounting strap.
4. Follow wiring instructions carefully (listed below).
5. Attach mounting strap to outlet box using box screws. provided with outlet box.
6. Mount fixture by aligning mounting holes in base with mounting screws, positioning the mounting screw heads through the large openings of the keyhole shaped slots. Rotate the fixture to seat the mounting screws, tighten mounting screws securely.
7. Install lamp(s) into socket(s).
8. Thread hexnut onto pipe nipple, leaving suffcient threads exposed. Thread pipe nipple into coupling, and secure by tightening hexnut to coupling.
9. Position glass shade on the fixture, allowing pipe nipple to pass through center hole in glass shade. Secure with hexnut to coupling.
10. Pat the cross decoration onto the bottom of glass and then secure with metal cap and finial.

CONNECTING THE WIRES (FIG .2)

11. At this point, connect the electrical wires as shown in Fig. 2, making sure that all wire connectors are secured. If your outlet box has a ground wire (green or bare copper), connect the fixture's ground wire to it. Otherwise, connect the fixture's ground wire directly to the mounting plate using the green screw provided. After wires are connected, tuck them carefully inside the Junction Box.
12. After wires are connected, tuck them carefully into the ceiling junction box.
13. Install the bulbs in accordance with the fixture's specifications. **(DO NOT EXCEED THE MAXIMUM WATTAGE RATING!)**

Your installation is now complete. Return power to the outlet box and test the fixture.

Fig.1

Mounting plate

Ground Screw

Mounting Screw (2)

Fig .2

FIXTURE WIRES Black or Smooth	FIXTURE WIRES White or Ribbed	FIXTURE WIRES Bare Copper (Ground)
HOUSE WIRES Black (Hot)	HOUSE WIRES White (Neutral)	HOUSE WIRES Green (Ground)